


A4 - Axial Head

Component Parts Breakdown



Ref	Qty	Description	EDP
1	1	Flange	4-001
2	1	Clutch	4-002
3	1	Operating Ring	4-003
4	1	Spring Housing	4-004
5	1	Gear Ring	4-005
6	3	Gear Sectors	4-006
7	1	Center Plate	4-007
8	1	Front Plate	4-008
9	1	Shank 1-1/2	4-009
9A	1	Shank 2"	4-009A
9B	1	Shank 40mm	4-009B
9C	1	Shank 50mm	4-009C
10	1	Pin	4-010
11	1	Coil Spring	4-011
13	4	Spring Pin	4-013
14	3	Eccentric Spindles	4-014
15	3	Spacer Studs	4-015

Ref	Qty	Description	EDP
18	3	Thread Roll	
19	116	Steel Ball	4-019
21	57	Needle Roller Bearings	4-021
21*	3	Carbide Bushing	1462
22	3	Fitting Key	4-022
23	4	Pressure Ring	4-023
24	3	Cap Screw	4-024
25	3	Cap Screw	4-025
26	6	Cap Screw	4-026
27	6	Stud	4-027
28	8	Cap Screw	4-028
29	6	Hex Nut	4-029
30	6	Washer	4-030
31	3	Lock Washer	4-031
32	1	Steel Ball	4-032
33	3	Shear Pins	4-033

Ref	Qty	Description	EDP
34	3	Roll Pins	4-034
35	1	Stop Screw Body	4-035
36	1	Stop Screw Body	4-036
37	1	Hex Nut	4-037
39	1	Hex Nut	4-039
40A	1	Handle Assy.	4-040A
41	3	Fitting Key	4-041
42	1	Rotating End Stop	4-042
43	1	Circlip	4-043
44	6	Circlip	4-044
47	3	Clutch Wedge	4-047
48	3	Cover Plate	4-048
49	1	Fitting Key	4-049
50	2	Cap Screw	4-050
51	3	Cap Screw	4-051



RSVP Tooling, Inc.

Toll Free: 888-289-7787 • Direct: 815-725-3310

Fax: 815-725-3391 • Email: sales@rsvptooling.com

www.rsvptooling.com